



LUND
UNIVERSITY


NANO
LUND

AT THE FOREFRONT
OF NANOSCIENCE

Synthesis of aerosol nanoparticles and nanowires at LNL

Martin H. Magnusson

Solid State Physics / NanoLund
Lund University, Sweden



Nanoparticle synthesis at Lund Nano Lab




**NANO
LUND**
AT THE FOREFRONT
OF NANOSCIENCE

- Metal and semiconductor particles
- Three main principles:
 - Evaporation of seed/core material
 - Modification of the particles
 - Tandem DMA setup
- Main uses:
 - Seeding nanowire growth on substrates
 - Metallic particles for catalysis
 - Nanotoxicology
 - Aerotaxy


Nanoparticle Generation

Evaporation/Condensation




Gold

Agglomerate Particles




Spark Discharge (SDG)



Size control – DMA

Differential Mobility Analyzer






LUND
UNIVERSITY

NANO
LUND

AT THE FOREFRONT
OF NANOSCIENCE



Cylindrical DMA





Electrostatic precipitator (ESP)

LUND
UNIVERSITY



$$d_{spot} = \sqrt{\frac{\phi h}{\pi U Z}}$$

Aerosol particle generation system




LUND
UNIVERSITY

NANO
LUND

AT THE FOREFRONT
OF NANOSCIENCE


Magnusson, M. H., et al. "Semiconductor nanostructures enabled by aerosol technology." *Frontiers of Physics* (2014) 9: 398-418



The real system



Substrate with gold nanoparticles



LUND
UNIVERSITY


NANO
LUND

AT THE FOREFRONT
OF NANOSCIENCE

- 2 DMAs gives higher quality
 - Better size control
 - More well-defined particles
- 1 DMA gives higher concentration
 - Especially at larger sizes
 - Often good enough
 - Example at left
 - $80 \text{ nm } 2 \mu\text{m}^{-2}$


Use of particles

Seeding nanowire growth




T. Mårtensson et al., Nano Lett. (2004) 4: 1987

Nanotrees



K.A. Dick et al., Nano Lett. (2006) 6: 2842




S. Franzén et al., *In preparation* (2020)

Magnetic particles
Exploratory materials
science

Nanotoxicology

Mass production of nanowires?

- Nanowires are normally grown by MOVPE
- Batch process, cycle time ≥ 30 min (today 2 h)
- Largest machine can handle a few 300 mm wafers
- Wires typically grow 1–10 nm/second
- Currently not an alternative for large surfaces






LUND
UNIVERSITY

NANO
LUND


AT THE FOREFRONT
OF NANOSCIENCE

Aerotaxy principle




Growth dependence on...


Seed particle size



Temperature



Time



M. Heurlin *et al.*,
Nature **492**, 90 (2012)



NANO
LUND

LUND
UNIVERSITY

AT THE FOREFRONT
OF NANOSCIENCE

Aerotaxy tool "Gen. 3.5"






NANO
LUND


LUND
UNIVERSITY

AT THE FOREFRONT
OF NANOSCIENCE

Aerotaxy tool "Gen. 3.5"




Baseline GaAs Nanowires



80 nm diameter \pm 20 %

Length 2.8 μm \pm 15 %



GaAsP

W. Metaferia *et al.*, Nano Lett. **16**, (2016), 5701

GaAs:Zn

F.F. Yang *et al.*, J Crystal Growth **414**, 161 (2015)

GaAs:Sn


W. Metaferia *et al.*, Nanotechnology **29**, 285601 (2018)
A. Persson *et al.*, Small, **14**, 1801285 (2018)

GaAs *pn*

E. Barrigón *et al.*, Nano Lett **18**, 1088 (2017)


“Mass production”

- 1 hour of collecting GaAs wires on a filter
 - Measured: 1.6 mg
 - Calculated: 1.85 mg
(80 nm x 2 μm)
- MOVPE comparison:
 - 100 mm wafer with 4 wires/ μm^2
 - Aerotaxy needs no lithography to define size selected seeds
 - Scalable!




Aerotaxy Gen 4

- Sol Voltaics' lab in Lund
- Pre-pilot production
- Up to six growth stages
- Demonstrated upscaled production capability




Images by Luke Hankin, Sol Voltaics AB

Aerosol safety studies



Conclusion: some particles can be measured during maintenance, but our safety arrangements are adequate



The Aerotaxy team

PhD students

- Sudhakar Sivakumar
- Axel R. Persson
- Irene Geijselaelers
- *Fangfang Yang*
- *Dr. Robert Hallberg*
- *Dr. Olof Hultin*
- *Dr. Kilian Mergenthaler*
- Bengt Meuller

@ Lund University

Post-docs

- Yang Chen
- *Enrique Barrigón*
- *Wondwosen Metaferia*
- *Nicklas Anttu (Aalto U)*

Faculty

- Jonas Johansson
- Mats-Erik Pistol
- L. Reine Wallenberg
- Knut Deppert
- Lars Samuelson



LUND
UNIVERSITY

NANOLUND
A GREAT PLACE TO DO NANOSCIENCE

*Knut och Alice
Wallenbergs
Stiftelse*



Vetenskapsrådet



Crafoordska stiftelsen
GRUNDAD AV HOLGER CRAFOORD 1980



H2020: Nano-Tandem 641023

@ Sol Voltaics

- Linda Johansson
- Dr. Magnus Heurlin
- Dr. David Lindgren
- Farnaz Yadegari
- Sung Youn Ju
- Dr. Greg Alcott

- Dr. Mikael Björk
- Dr. Luke Hankin

martin.magnusson@ftf.lth.se

